

12. Second, attach the headlight to the bracket at desired level.



Attaching the Handlebars

13. Attach the Handlebars to the headstem at the desired height. Fasten bolts tight with an allen key.



14. Fit the front wheel and tighten with the quick release bolt.

Attaching the Back light

15. Lastly, fix the back safety light into the position as shown in picture. Push orange button to operate.



Congratulations, your VALLKREE Electric Bicycle is assembled!



Thereafter, we recommend all VALLKREE Electric Bicycles receive regular maintenance from a bicycle mechanic.

We recommend all VALLKREE Electric Bicycles are kept under cover when not in use.